



TECH TIPS

- **Caution:** the fluid level rises with higher temperatures and with the number and size of the probes placed into the fluid.
- Best results are obtained with the probe inserted to the full depth of the well.
- The stabilization time of the Micro-Bath depends on the conditions and temperatures involved. Typically stability is achieved within ten minutes.

To perform the test:

- STEP 1** Place the calibrator on a flat surface with at least six inches of free space around the instrument.
- STEP 2** Carefully insert the probe basket into the well and fill with the appropriate fluid.
- STEP 3** For optimal performance allow the manufacturer-recommended warm-up period.
- STEP 4** Insert the test probe to be calibrated into the well of the bath. For best performance, also insert a temperature standard for comparison.
- STEP 5** Once the probe is inserted to the full depth of the bath, allow adequate stabilization time for the test probe temperature to settle.
- STEP 6** Once the probes have settled to the temperature of the bath, their indication may be compared to the calibrator display temperature (or to a temperature standard such as a 1551A).

Additional resources

For more in depth information about this application check out these videos and application notes from Fluke.



Industrial Temperature Calibrators Workload Matrix

Process Calibration Tools: Temperature Applications